


H 16-44
 (1) To open the body shell
 (a) Remove the body shell by lifting the shell;
 (2) For digital command control (DCC) use (optional)
 a. After removing the body shell (see instruction 1);
 b. Remove the weight by unscrewing a screw;
 c. Simply remove the dummy plugs and install the DCC compatible decoder (see diagram A).

"N" SCALE DCC WIRING INSTRUCTION



JOIN NO. ON PCB	1	2	4	5	6	7	8
WIRING TO:	MOTOR	REVERSE LIGHT	POWER LEFT	MOTOR	FORWARD LIGHT	LIGHT COMMON	POWER RIGHT
WIRE COLOR	ORANGE	YELLOW	BLACK	GREY	WHITE	BLUE	RED