

LISTA DE RECAMBIOS / LIST OF SPARES

Número Number	Descripción Description	Ref. repuesto Spare part ref.
1	Tapa techo Roof cover	ER3802/01
2	Set pasamanos Handrails set	ER3800/02
3	Set pasamanos Handrails set	ER3800/03
5	Set iluminación Lighting set	ER3810/05
6	Set placas Plates set	ER3810/06
7	Cabina Cabin	ER3800/07
8	Set accesorios superiores Upper accessories set	ER3802/08
9	Set pasamanos frontales Front handrails set	ER3800/09
10	Circuito impreso PCB	ER3810/10
11	Set accesorios frontales Front accessories set	ER3810/11
12	Set motor Motor set	ER3810/12
13	Set topes Buffers set	ER3800/13
14	Caja enganche Coupling box	ER3800/14
15	Enganche Coupling	ER058
16	Set Chasis Chassis set	ER3810/16
17	Set de Peldaños Steps set	ER3802/17
18	Set areneros Sandboxes set	ER3800/18
19	Set accesorios topera Buffers holder set X2	ER3800/19
20	Toma corriente Current pick-up	ER3800/20
21	Set caja de engranajes Gear box set	ER3800/21
22	Base bogie Bogie base	ER3800/22
23	Base bogie AC AC Bogie base	ER3800/23
24	Set engranajes Gears set	ER3800/24
25	Rueda con engranaje y aro DC DC Geared wheel set with ring	ER3800/25
27	Rueda con engranaje sin aro DC DC Geared wheel set without ring	ER3800/27
29	Set de bielas Rods set	ER3800/31
31	Bolsa de accesorios Accessories bag	ER3810/31

