



Para desmontar la carrocería, desatornillar los tornillos 1 y 2. **Sólo desatornillar los tornillos 3 y 4, si se quiere acceder a los ejes.**

To open this locomotive please remove the screws 1 and 2. **Do not remove the screws 3 and 4 unless you want to remove the wheel sets.**

LIST OF SPARES

Item No	Description	Spare part ref.
1	Body shell	ER0047/01
2	Body shell accessories set	ER0047/02
3	Pistons	ER0038/03
4	Weight	ER10100/04
5	Printed circuit board	ER0038/05
6	Gear with axle	ER10100/06
7	Motor set	ER0040/07
8	Chassis	ER0034/08
9	Rod set	ER10100/09
10	Wheel sets	ER0047/10
11	Chassis bottom include current pick-ups	ER10100/12
12	NEM coupler heads	ER061
13	OO scale coupler heads	R8219A
14	Coupler boxes	ER10100/14



GOLDEN VALLEY HOBBIES
 Unit 1, Pontrilas Business Park,
 Pontrilas, Herefordshire, HR2 0AZ
 United Kingdom
www.GoldenValleyHobbies.com