


LIST OF SPARES

Item No	Description	Spare part ref.
1	Bodyshell	ER0037/01
2	Bodyshell accessories set	ER0037/02
3	Pistons	ER0035/03
5	Printed circuit board	ER0035/05
6	Gear with axle	ER10100/06
7	Motor set	ER0035/07
8	Chassis	ER0035/08
9	Rods set	ER10100/09
10	Wheel sets	ER0037/10
12	Chassis bottom include current pick-ups	ER0035/12
13	Coupling (x2)	R8219A
14	Coupler box (x2)	ER10100/14
15	Poly Bag	ER061



To open this locomotive please remove the screws 1, 2 and 3.

Do not remove the screws 4 and 5 unless you want to remove the wheel sets.