



## TENDER DRIVE RING FIELD MOTOR UNIT TYPE 2 as produced from January 1976 Used with R.061 and R.063

NOTE: Remove centre wheel to take out X.802 Assembly.

Modifications are made to models from time to time. If a spare part is required which does not coincide with the illustration, a full description should be given and, if necessary, a sketch or sample should accompany the order.



## TENDER DRIVE RING FIELD MOTOR UNIT Used with earlier R.550, R.552, R.859 and R.861



**ROVEX Service Centre** Albert Street, Ramsgate, Kent, CT11 9HD, England.

**SERVICE SHEET No.98A**  
Issued September 1976  
Supersedes Sheet No.98

## List of Parts

### TENDER DRIVE RING FIELD MOTOR UNIT

Cat. No.	Item	For Rovex internal use only
X.171	Coupling Unit .....	R009-0322
X.800	Motor/Chassis Assembly (R.550, R.859, R.861) .....	-
X.801	Side Plate Assembly (R.550, R.859, R.861) .....	R862-0472
X.802	Armature Magnet Assembly .....	R862-0562
X.803	Armature Assembly .....	R862-0324
X.804	Chassis Assembly (R.550, R.552, R.859, R.861) .....	-
X.805	Driving Wheel - Tyred - Spoked (R.550, R.552, R.859, R.861) .....	-
X.806	Chassis Frame Assembly (R.550, R.552, R.861) .....	-
X.816	Driving Wheel - Flangeless Tyred - Spoked (R.550, R.552, R.859, R.861) .....	-
X.825	Chassis Frame Assembly (R.859) .....	R858-0021
X.846	Side Plate Assembly (R.552) .....	-
X.847	Motor/Chassis Assembly (R.552) .....	-
X.860A	Driving Wheel - Tyred - Disc (R.061, R.063) ..	R062-0722
X.887	Side Plate Assembly - Disc (R.061, R.063) .....	R062-0762
X.888	Driving Wheel - Flangeless (R.061, R.063) .....	R062-0482
X.889	Chassis Assembly (R.061, R.063) .....	-
X.890	Motor/Chassis Assembly (R.061, R.063) .....	R062-0575
X.896	Chassis Frame Assembly (R.061) .....	R062-0021
X.897	Chassis Frame Assembly (R.063) .....	R064-0061
S.1070	Screw - Coupling Unit .....	Z100-0300
S.1158	Screw - Side Plate Assembly .....	Z100-0460
S.1180	Screw - Weight Fixing .....	Z100-0510
S.2290	Spur Gear - 11 Tooth .....	R862-0700
S.2326	Axle .....	R862-0830
S.2361	Driving Wheel - All Metal - Disc (R.061, R.063) ..	R062-0470
S.3747	Commutator Washer .....	R862-0810
S.3766	Brush Cap .....	R862-0490
S.4282	Weight .....	R860-0560
S.8312	Spur Gear - 40 Tooth .....	R862-0040
S.8313	Spur Gear - 40/10 Tooth .....	R862-0050
S.8318	Traction Tyre .....	R862-0820
S.8319	Carbon Brush .....	R863-0850
S.8382	Brush Spring .....	R862-0860
S.8383	Circlip .....	R862-0840

### Notes

**ROVEX Service Centre**  
ALBERT STREET, RAMSGATE,  
KENT, CT11 9HD, ENGLAND.