
CLASS 25 DIESEL LOCOMOTIVES-R.068, R.072



When assembling the non-powered bogie ensure that the insulated wheels (shaded centres) are on the correct side.

Modifications are made to models from time to time. If a spare part is required which does not coincide with the illustration, a full description should be given and, if necessary, a sketch or sample should accompany the order.

use a small screwdriver blade to ease the Frame off the clip at the opposite end.

HORNBY HOBBIES

Westwood, Margate, Kent, CT9 4JX, England. SERVICE SHEET No.107 Issued June 1978

HORNBY RAILWAYS

CLASS 25 DIESEL LOCOMOTIVES-R.068, R.072

List of Parts

| Cat. No | Item | For Rovex internal use only |
|---------|---------------------------------------|-----------------------------------|
| X.936 | Wheel/Axle Assembly-Non-Powered Bogie | |
| X.942 | Motor/Chassis Assembly | |
| X.944 | Non-Powered Bogie Assembly | |
| X.945 | Powered Bogie Assembly | |
| X.948 | Body Assembly (R.072) | |
| X.949 | Body Assembly (R.068) | |
| X.1083 | Wire Lead Assembly | |
| X.1085 | Diode Assembly | |
| X.1086 | Wire Lead Assembly | |
| X.1087 | Wire Lead Assembly | |
| S.3192 | Coupling Hook | R009-0310 |
| S.4323 | Weight | R317-0580 |
| S.4329 | Chassis - Non-Powered Bogie | R068-0570 |
| S.4346 | Wiring Connector | R068-0030 |
| S.8911 | Buffer - Round Head | R041-0070 |
| S.9630 | Bogie Frame | R068-0030 |
| S.9655 | Glazing Unit | R068-0040 |
| S.9666 | Cab Interior | R068-0020 |
| S.9669 | Chassis | R068-0060 |
| S.9674 | Light Bulb Shield | R317-0740 |
| S.9855 | Light Bulb — 14 volt, 0.04 amp | R068-0760 |

Notes

For lubricating instructions refer to the Hornby Locomotive Operation and Maintenance leaflet.

Haulage power of diesel locomotives is greater when the non-powered bogie leads the powered bogie.

The bogie assemblies are designed to be a loose fit in the chassis to allow the wheel/rail surfaces to maintain contact under most circumstances.

The hole in the glazing section is provided to enable the owner to fit a Seuthe No. 100 Smoke Unit. Care must be taken to insulate the glazing section and body from the heat created. A power unit of sufficient capacity will be needed.

ROVEX SERVICE CENTRE, ALBERT STREET, RAMSGATE, KENT. CT11 9HD, ENGLAND.

SERVICE SHEET No.107

HORNBY HOBBIES