



LIST OF SPARES

Item No	Description	pack	R2227/R2394	R2228	R2249	R2229	R2395	R2393
1	Cylinder Block	1	X9154	X9154	X9154W	X9154	X9154W	X9154
2	Valve Gear Assembly	set	X9155	X9155	X9155W	X9155	X9155W	X9155
3	Coupling Rods	set	X9156	X9156	X9156W	X9156	X9156W	X9156
4	Loco Wheel Set	set	X9157	X9161	X9264W	X9264	X9157W	X9264
5	Motor Assembly	1	X9018	X9018	X9018	X9018	X9018	X9018
6	Gear Set	set	X8849	X8849	X8849	X8849	X8849	X8849
7	Pony Truck	1	X4721	X4721	X4721W	X4721	X4721W	X4721
8	Drawbar Assembly	1	X8846	X8846	X8846	X8846	X8846	X8846
9	PCB Socket + Pins	1	X9084	X9084	X9084	X9084	X9084	X9084
10	Motor Retainers	1+1	X9158	X9158	X9158	X9158	X9158	X9158
11	Chassis Bottom	set	X9159	X9159	X9159W	X9159	X9159	X9159
12	Couplings	10	X9072	X9072	X9072W	X9072	X9072W	X9072
13	Tender Chassis Assembly	1	X9031	X9031	X9031W	X9031	X9031W	X9031
14	Tender Wheels	set	X9082	X9334	X9082W	X9082	X9082W	X9334
15	Tender Chassis Bottom + Screws	1	X8949	X8949	X8949W	X8949	X8949W	X8949
16	Assembly Bag	1	X4731	X4731	X4731W	X4731	X4731	X4731
*	Small Parts Pack	1	X9160	X9160	X9160	X9160	X9160	X9160