



4* is positioned UNDERNEATH the chassis

LIST OF SPARES

Item	Description	Pack	R2488	R2489	R2490
1	Drive Unit Complete	1	X9395	X9395	X9395
2	Cam for Couplings and Springs	set	X9396	X9396	X9396
3	Pcb Main Board	1	X9397	X9397	X9397
4	Pcb Light Switch Unit* (not shown)	1	X9398	X9398	X9398
5	Wire Joiners	18	X9236	X9236	X9236
6	Buffer Assembly	4	X9399	X9399	X9399
7	Motor Unit and Pads	1	X9400	X9400	X9400
8	Worm Pinion Shaft Assembly	set	X9401	X9401	X9401
9	Universal Joints	10	X9244	X9244	X9244
10	Doors	pack	X9402	X9403	X9404
11	Contacts in Cab / Plate	1	X9405	X9405	X9405
12	Front Lights / Cab Unit	1	X9406	X9407	X9408
Not illustrated	Rear Lights / Cab Unit	1	X9409	X9410	X9411
14	Small Coupling Assembly	1	X5069	X5069	X5069
15	Coupling Pack (coupling + pocket)	pack	X9412	X9412	X9412
Not illustrated	Assembly Bag	pack	X5593	X5593	X5593