



LIST OF SPARES

| Item No. | Description | Pack | R2580, R2723 | R2581 | R2582, R2724 | R2583, R2725 | R2638 |
|----------|---|-------|--------------|--------|--------------|--------------|-------|
| 1 | Motor Retainers | pack | X9150 | X9150 | X9150 | X9150 | X9150 |
| 2 | Motor | 1 | X4026 | X4026 | X4026 | X4026 | X4026 |
| 3 | Cylinder Block | 1 | X9457 | X9468W | X9468 | X9468 | X9468 |
| 4 | Loco Wheel set | set | X9458G | X9458W | X9458 | X9458 | X9458 |
| 5 | Valve Gear Set Assembled including Gear Support | set | X9459 | X9459W | X9459 | X9459 | X9459 |
| 6 | Coupling Rod Set | set | X9460 | X9460W | X9460 | X9460 | X9460 |
| 7 | Bogie Assembly | 1 | X9461G | X9461W | X9461 | X9461 | X9461 |
| 8 | Drawbar | 1 | X8846 | X8846W | X8846 | X8846 | X8846 |
| 9 | Bogie Bracket Screw / Nut | pack | X9462 | X9462W | X9462 | X9462 | X9462 |
| 10 | Loco Chassis Bottom | 1 | X9463 | X9463W | X9463 | X9463 | X9463 |
| 11 | Gear Set | set | X3875 | X3875 | X3875 | X3875 | X3875 |
| 12 | PCB Socket + Pins | 1 + 1 | X9084 | X9084 | X9084 | X9084 | X9084 |
| 13 | Coupling Pack | 10 | X9289 | X9289 | X9289 | X9289 | X9289 |
| 14 | Tender Chassis | 1 | X9465 | X9465W | N/A | X9465 | X9465 |
| 15 | Tender Chassis | 1 | N/A | N/A | X9469 | N/A | N/A |
| 16 | Tender Wheel Set | set | X9466 | X9466W | N/A | X9466 | X9466 |
| 17 | Tender Wheel Set | set | N/A | N/A | X9471 | N/A | N/A |
| 18 | Wheel Chassis Holder Tender | 1 | N/A | N/A | X9464 | N/A | N/A |
| 19 | Bogies (no Wheels) | pack | X9470 | X9470W | N/A | X9470 | X9470 |
| 20 | Small Coupling Assembly | 1 | X5069 | X5069W | X5069 | X5069 | X5069 |
| 21 | Assembly Bag | pack | X5899G | X5899W | X5900 | X5899 | X5899 |

N.B. There is only one pair of steps per assembly bag