



SMALL RADIUS TURNOUT LEFT HAND

Code 80 (SETRACK RANGE)
ST-6 *Insulfrog*




SMALL RADIUS TURNOUT RIGHT HAND

Code 80 (SETRACK RANGE)
ST-5 *Insulfrog*




Use this scale bar to check that your printer is printing at 100%



SHORT CROSSING

Code 80 (SETRACK RANGE)

ST-7 Insulfrog



Use this scale bar to check that your printer is printing at 100%

