


SINGLE SLIP


Code 55

SL-380F *Insulfrog*

SL-E380F *Electrofrog*




Use this scale bar to check that your printer is printing at 100%



SCISSORS CROSSING


Code 55

SL-E383F *Electrofrog*



271mm (10.669")

Use this scale bar to check that your printer is printing at 100%



These plans are produced by the manufacturers and may be reproduced by modellers for the purpose of layout building. Commercial copying or reproduction prohibited.

© PRITCHARD PATENT PRODUCT CO. LTD, BEER, DEVON EX12 3NA ENGLAND


**CURVED DOUBLE RADIUS TURNOUT
LEFT HAND**

Code 55
SL-E387F *Electrofrog*




**CURVED DOUBLE RADIUS TURNOUT
RIGHT HAND**

Code 55
SL-E386F *Electrofrog*




Use this scale bar to check that your printer is printing at 100%




These plans are produced by the manufacturers and may be reproduced by modellers for the purpose of layout building. Commercial copying or reproduction prohibited.

© PRITCHARD PATENT PRODUCT CO. LTD, BEER, DEVON EX12 3NA ENGLAND



LARGE RADIUS TURNOUT
LEFT HAND


Code 55
SL-E389F *Electrofrog*



LARGE RADIUS TURNOUT
RIGHT HAND

Code 55
SL-E388F *Electrofrog*

Use this scale bar to check that your printer is printing at 100%



These plans are produced by the manufacturers and may be reproduced by modellers for the purpose of layout building. Commercial copying or reproduction prohibited.


© PRITCHARD PATENT PRODUCT CO. LTD, BEER, DEVON EX12 3NA ENGLAND

DOUBLE SLIP


Code 55

SL-390F *Insulfrog*

SL-E390F *Electrofrog*




Use this scale bar to check that your printer is printing at 100%




SMALL RADIUS TURNOUT LEFT HAND

Code 55
SL-E392F *Electrofrog*




SMALL RADIUS TURNOUT RIGHT HAND

Code 55
SL-E391F *Electrofrog*




Use this scale bar to check that your printer is printing at 100%



SHORT CROSSING


Code 55

SL-E393F *Electrofrog*



104mm (4.094")

Use this scale bar to check that your printer is printing at 100%




LONG CROSSING


Code 55

SL-394F *Insulfrog*

SL-E394F *Electrofrog*




Use this scale bar to check that your printer is printing at 100%




MEDIUM RADIUS TURNOUT LEFT HAND

Code 55
SL-E396F *Electrofrog*




MEDIUM RADIUS TURNOUT RIGHT HAND

Code 55
SL-E395F *Electrofrog*




Use this scale bar to check that your printer is printing at 100%




Y TURNOUT MEDIUM RADIUS

Code 55

SL-E397F *Electrofrog*




Use this scale bar to check that your printer is printing at 100%



ASYMMETRIC THREE WAY TURNOUT

Code 55
SL-E399F *Electrofrog*



153.25mm (6ins)

Use this scale bar to check that your printer is printing at 100%

