



Dome Assembly

Note tab at the end of dome





Note 2 different tab positions near ends of domes: at ENDS of domes and SET BACK from ends of domes. Finish dome assembly by sliding ends into position at ENDS WITH TABS.




IMPORTANT



DO NOT assemble domes in outer slots. Insert domes into inner tab slots ONLY. (Outer tab slots are used for joining another station if desired.)



Two joined stations are shown only for illustrative purposes. (Two kits can be combined to make this configuration.)



OR



Note: Labels 7-10 needed only if second station added

HTB39-IS001

Direct inquiries to:

Attention: Service Department
Bachmann Industries, Inc.
1400 East Erie Avenue
Philadelphia, PA 19124
USA

Telephone: 800-356-3910 (toll free within the United States and Canada only)
Telephone: 215-533-1600 (for all countries)

E-mail: service@bachmanntrains.com

Printed in China

Demande de renseignements à :

Service d'entretien
Bachmann Industries, Inc.
1400 East Erie Avenue
Philadelphia, PA 19124
E.-U.

Téléphone : 1 800 356-3910 (sans frais aux États-Unis et au Canada seulement)
Téléphone : 1 (215) 533-1600 (pour tous les pays)

Courriel : service@bachmanntrains.com

Impreso en China