



Para desmontar la carrocería, desatornillar los tornillos 1 y 2. **Sólo desatornillar los tornillos 3 y 4, si se quiere acceder a los ejes.**

To open this locomotive please remove the screws 1 and 2. **Do not remove the screws 3 and 4 unless you want to remove the wheel sets.**

#### LIST OF SPARES

Item No	Description	Spare part ref.
1	Body shell	ER0046/01
2	Body shell accessories set	ER10100/02
3	Pistons	ER0038/03
4	Weight	ER10100/04
5	Printed circuit board	ER0038/05
6	Gear with axle	ER10100/06
7	Motor set	ER0040/07
8	Chassis	ER0034/08
9	Rod set	ER0033/09
10	Wheel sets	ER0046/10
11	Chassis bottom include current pick-ups	ER10100/12
12	NEM coupler heads	ER061
13	O0 scale coupler heads	R8219A
14	Coupler boxes	ER10100/14



**GOLDEN VALLEY HOBBIES**

Unit 1, Pontrilas Business Park,  
Pontrilas, Herefordshire, HR2 0AZ  
United Kingdom

[www.GoldenValleyHobbies.com](http://www.GoldenValleyHobbies.com)